Rev1.0

# **iSO-CAT6** Operating instructions

#### Precaution

### Please read this instruction carefully before use.

- Do not attempt to disassemble or modify the product.
- Keep the product away from the external shocks or vibrations.
- Do not use the damaged or peeled cables.
- Do not use the unit outdoors.
- Product specifications and features are subject to change without notice.

#### **Warranty Information**

- Free warranty service
  - In case of the defect is found caused by the design or the production flaw while using the device properly, a manufacturer is responsible for the faulty product and the free warranty service for 1 year from the date of purchasing.
  - Even in the warranty service period, malfunction or damage of products caused by the inevitable incident such as a natural disaster is not subject of the free warranty service.
- Warranty service at a cost
  - The product that free warranty service period is expired.
  - Malfunction of the product caused by a user's fault.
  - Malfunction of the product caused by incidents.
  - Malfunction of the product caused by a natural disaster such as earthquake, flood, lightning & etc.
  - In case of the warranty service at a cost, a customer should cover the transportation costs.
- Samples of a user's fault
  - In case of attempts to disassemble or modify the device
  - In case of not following the instructions on this manual
- Please read this operating instructions & Q&A board on our website carefully before asking for the warranty service.


## Supplied components


- iSO-CAT6 Unit
- LAN cable
- Operating Instruction



## Product user guide

- iSO-CAT6 is a LAN signal isolator to enhance the audio sound quality. By using the specially designed filter which isolates LAN signal and blocks noise, iSO-CAT6 extremely improves the sound quality.
- As the image below, connect the router to the ROUTER jack of iSO-CAT6 by the lan cable which was connected to the device originally and connect the device(a music server, pc or NAS) to the DEVICE jack of iSO-CAT6 by the supplied LAN cable.
- Please make sure that all connections must be made after turning off all devices.





- ① DEVICE Jack: Connect to a music server, PC or NAS by the supplied LAN cable.
- 2 ROUTER Jack: Connect to a router or network hub by LAN cable.

## Specification

- Isolator specification
  - CAT6 support
  - Fully shielded modular jack
  - High quality isolation transformer
  - Isolation 1500Vrms, 0.5mA, 60sec
- Others
  - High-end audio grade sound tuning
  - No need external power supply

